ENERGATE
interactive energy management solutions

QUICK START GUIDE

FOUNDATION™

Manage Home Energy

Energy Management Tools

To avoid power outages and rising energy costs, your utility sends pricing information and/or energy events to manage energy use. Customers who participate in these events will reduce their energy consumption and save money. Your new thermostat will help you manage your energy use.

Energy Saving Event

The Blue light indicates there is an Energy Saving Event active and the thermostat has adjusted the temperature to save energy. To quickly override a voluntary event, press ▲ or ▼ to adjust the temperature.

View Energy Costs

Press ✓ and select Consumption Information. You can cycle through the various energy screens using the ✓ button to see your current, daily, and monthly energy costs & use.

Balance Savings & Comfort

Press ✓ and navigate to >Events Response Settings>Conservation Settings. This will help determine how much temperature offset will be enabled when a price increase occurs. Note: Maximum Comfort setting will ignore all rate increases.

Control the Temperature

Set Thermostat Mode & Fan Settings

Press ✓ and select *Mode & Fan Settings*. Select the Mode you would like to use:



- OFF — heating and cooling systems are off but the fan may still run for home ventilation
- COOL — only the cooling system is on and used
- HEAT — only the heating system is on and used
- AUTO — automatically selects heat or cool to maintain the target temperature
- EMERGENCY HEAT — engages emergency heat – only appears if you have a heat pump with auxillary heat

After selecting the desired Mode, the Fan Settings screen appears. Normally this is set to AUTO. However, if you would like your fan to circulate air constantly change this setting to ON.

Change the Temperature Temporarily

Press ▲ or ▼ until your desired temperature is displayed. The hold will remain in effect until the next schedule change.

Cancel a Temporary Temperature Hold

Press ✓ and navigate to >*Temperature Hold*>*Cancel Hold*. Select Yes to confirm cancellation.

Program a Schedule

If you wish to customize the default schedule, press ✓ and navigate to >Schedule Settings>Edit Current Schedule (for a specific setpoint) or >Schedule Settings>Reset Schedule Wizard to reset your entire schedule.

Set and Change Display Options

Press ✓ and navigate to >Settings>Display Options. From here, you can change settings including temperature units, and standby brightness.

Customer Service

Model Number: FZ100

Support Contact:

Accessing Your Thermostat On the Web: (if applicable)

Go To:

Your Login:

Your Password:

FOUNDATION™

SMART THERMOSTAT AND
HOME ENERGY GATEWAY

$ ENERGY DISPLAY

The **energy display** shows electricity consumption and rate information. Use this information to make informed decisions about your home comfort and consumption settings.



1. Touch any button to wake your unit
2. Press Home button to switch between Energy and Temperature Display
3. Press the Home button to exit or cancel from the menu



Press Select
to Access:

- Consumption Information
- Mode & Fan Settings
- Schedule
- Temperature Hold
- and more

Press Select

THERMOSTAT DISPLAY

The **thermostat display** provides climate control and comfort settings. You can adjust the temperature, program a schedule, and change the thermostat mode and fan settings for your home.



ENERGATE
interactive energy management solutions

Visit www.energateinc.com/foundation to download the complete user manual.

©2013 All Rights Reserved